



CONCRETE MOUNTING GUARD INSTALLATION

1. Install CGB-150 concrete mounting guard making sure the top edge of the ring lines up with the top edge of the transformer cover. Secure side bands to the bottom of transformer with #10 self-tapping screws provided.

NOTE: Side bands of CGB-150 may be bent outward to adjust the fit of the top ring.

2. Follow concrete pour instructions on **ITT** Transformer installation instructions.

